



To expand signal coverage or fill signal blind area where signal is weak or unavailable. Outdoor: Airports, tourism regions, golf courses, tunnels, factories, mining districts, villages, ... Indoor: Hotels, exhibition centers, basements, shopping malls, offices, parking lots, ...