

## JTD-CBx Series



JTD-CBx Series Cross Combiners



JTD-CBx Series Cross Combiners

?: ????  
*On Order*  
★★★★★

[?????????](#)

??

## **INDEX**

<a href="#">DIPLEXER (68-490/698-3800MHz)</a> .....	2
<a href="#">DIPLEXER (80-2690/3300-5925MHz)</a> .....	4
<a href="#">DIPLEXER (690-960/1710-2690)</a> .....	6
<a href="#">DIPLEXER (698-803/880-960)</a> .....	8
<a href="#">DIPLEXER (698-2170/2300-2700)</a> .....	10
<a href="#">DIPLEXER (1710-1880/1920-2200)</a> .....	12
<a href="#">DIPLEXER (698-2700/3300-3800)</a> .....	14
<a href="#">TRIPLEXER (380-960/1710-2170/2300-2700)</a> .....	16
<a href="#">TRIPLEXER (690-960/1710-1880/1920-2170)</a> .....	18
<a href="#">TRIPLEXER (690-960/1710-2170/2300-2690)</a> .....	20
<a href="#">TRIPLEXER (1710-1880/1920-2170/2300-2690)</a> .....	22
<a href="#">TRIPLEXER (698-960/1710-2170/3300-3800)</a> .....	24
<a href="#">TRIPLEXER (617-960/1710-2700/3300-4200)</a> .....	26
<a href="#">TRIPLEXER (1710-2170/2300-2700/3300-3800)</a> .....	28
<a href="#">QUADPLEXER (380-960/1710-1880/1920-2170/2300-2700)</a> .....	30

# JTD-CBx Series Cross Combiners

---

<u>QUADPLEXER (694-806/824-960/1710-1880/1920-2170).....</u>	<u>32</u>
<u>QUADPLEXER (690-960/1710-1880/1920-2200/2300-2700).....</u>	<u>34</u>
<u>QUADPLEXER (698-960/1710-2170/2300-2700/3300-3800).....</u>	<u>36</u>
<u>QUADPLEXER (1710-1880/1920-2170/2300-2700/3300-3800).....</u>	<u>38</u>
<u>PENTAPLEXER (694-806/824-960/1710-1880/1920-2170/2300-2700).....</u>	<u>40</u>
<u>PENTAPLEXER (698-803/824-894/1710-1880/2300-2700/3300-3800).....</u>	<u>42</u>
<u>PENTAPLEXER (698-960/1710-1880/1920-2170/2300-2400/2500-2700).....</u>	<u>44</u>
<u>PENTAPLEXER (698-960/1710-1880/1920-2170/2500-2690/3500-3800).....</u>	<u>46</u>
<u>PENTAPLEXER (698-960/1710-1880/1920-2170/2300-2690/3300-3800).....</u>	<u>48</u>
<u>PENTAPLEXER (380-960/1427-1880/1920-2170/2300-2690/3300-3800).....</u>	<u>50</u>
<u>HEXAPLEXER (698-806/824-960/1710-1880/1920-2170/2300-2700/3300-3800)...</u>	<u>52</u>
<u>HEXAPLEXER (698-798/824-894/1695-2180/2300-2400/2500-2690/3300-3800)...</u>	<u>54</u>
<u>7 COMBINER (698-798/824-960/1695-1880/1920-2200/2300-2400/2500-2690/3300-3800)</u>	<u>56</u>