#### 144~174MHz

# **VHF OMNI ANTENNA**



Communications Technology & Engineering Accessories

Rev.V1.0

## **Application:**

- ♦ 150MHz VHF Frequency
- **♦ Point-to-Multipoint**

#### **Product Character:**

- ♦ Well Performance
- FRP encapsulation
- Adapt to any climate environment
- ♦ Steel installation kit

Specification of 144-174MHz Outdoor Omni Antenna:

Model	JTD-F22	Product Picture
Frequency Range	144~174MHz	
Input Impedance	50(Ω)	
VSWR	≤ 1.50	
Gain	6.7 dBi	
Polarization	Vertical Polarization	
Туре	2 × 7/8 wave	
Maximum Power	200(W)	1 1 1 1
Connector Type	UHF-Female	
Length	3.2m	⇒ Y <del>~</del>
Material	Fiberglass, Copper	
Lightning Protection	DC Ground	
Working Temperature	-40~+80(°C)	
Wind Velocity	60m/s	
Weight	1.3(kg)	•

### **Installation Instruction:**

- 1. For the two-segment antenna, first connect and secure each segment of the antenna, and wrap it with waterproof tape.
- 2. Fix the antenna installation position on the erection pole with a clamp.
- 3. Connect the cable connectors properly and wrap the connector parts with waterproof tape.
- 4. Secure the cable with cable ties, and add a waterproof backflow section before the cable enters the room.
- 5. If conditions permit, please add non-metallic stay wires.

Note: The drawing only for reference, please make the object as the standard.